

Introduction

Introduction

This window used to start and stop the Individual operations of the manufacturing order.

Business Example

In a pump Industry once the manufacturing order is released and material for production is received for stores. The shop floor operator will start the production operations. For tracking the time taken (Duration real) for the operation, the operator will start the operation once he starts the production operation and once he finishes the operation he will stop the operation.

Revision #4

Created Tue, Apr 14, 2020 6:07 PM

Updated Tue, Apr 28, 2020 2:44 PM