

Parameters

The screenshot shows the 'Parameters' form within the 'Quality Test Plan' module. The form is divided into two main sections: 'Data requested' and 'User Decision Allowed'. The 'Data requested' section includes fields for Client (Konnect Demo), Quality plan (Machine Test), Parameter (Length), Parameter Type (Quantitative Parameter(Number,volume,etc)), and Controller (Inspector). The 'User Decision Allowed' section includes fields for Organization (Manufacturing Discrete), Sequence (10), Drawing Sub Number, Priority (Medium), and Frequency. There are also checkboxes for 'Active' and 'User Decision Allowed'.

Critical Fields

1. Parameter: Used to mention the parameter from the quality parameter master.
2. Controller: Used to select the controller.(Inspector or Operator)

Critical & onetime setup fields

1. Organization Field: This field is used to select the organization which you are going to process the document.

Non-Critical Fields

1. Drawing Sub Number: It is used to mention the drawing numbers and helps to print in reports.
2. Priority: We can select the Priority for the parameters.
3. Frequency: We can mention the frequency for this parameter.
4. User Decision Allowed: Once user decision is checked system will allow the user to over right the decision given by the system as per the record value in inspection screens.
5. Sequence: It is used to mention the order of the sequence.

Zoom condition's

Validation

Revision #7

Created Wed, Apr 22, 2020 7:02 PM by [Prasanth P](#)

Updated Wed, May 27, 2020 6:04 PM by [Harishprabu G](#)