

Tabs

- Inspection
- Results
- Attributes
- Consumables
- Quality Tools

Inspection

Critical Fields

- 1) Name- Enter the Name of the document.
- 2) Tester- Name of the person who is inspecting the component.

Critical & onetime setup fields

- 1) Organization Field- This Field is used to select the organization which you are going to process the order.

2) Target Document Type- This Field is used to select the type of the document that you are going to process.

Non-Critical Fields

1) Total Quantity- System will display the quantity from the selected Material receipt document. User can't edit the Quantity.

2) Sample Quantity- System will display the quantity from the selected Material receipt document. User can't edit the Quantity.

Serial number/Lot number (ASI)

Attribute can't be created in this document. Only attribute will be taken from the selected Source document.

Zoom condition's

1) Material Receipt

2) Shipment (Customer)

3) Subcontract Receipt

4) Inventory Move

5) Internal Use Inventory

6) NCR

Customization

Results

The screenshot shows the 'Results' page of the KONNECT ANALYTICS application. The interface includes a top navigation bar with the logo, a search bar, and user information. Below the navigation bar is a toolbar with various icons for navigation and actions. The main content area is titled 'Inspection > Results' and contains a form for entering inspection data. The form is organized into two columns. The left column contains fields for 'Client' (XYZ Foundation), 'Inspection' (1000623_sd00103), 'Product' (1000002_Connectors), 'Parameter' (Visual), 'Active' (checked), 'Record value' (200), 'Sample Qty' (10.00), 'QC Outcome(System)' (QC Not OK), and 'Reason'. The right column contains fields for 'Organization' (XYZ Offsite), 'Quality plan' (pc assembly), 'Attribute Set Instance', 'Value Low', 'Value High', 'Total Qty' (10.00), and 'QC Outcome(User)' (QC Ok). At the bottom right, there is a watermark for 'Activate Windows'.

Client	XYZ Foundation	Organization	XYZ Offsite
Inspection	1000623_sd00103	Quality plan	pc assembly
Product	1000002_Connectors	Attribute Set Instance	
Parameter	Visual		
Active	<input checked="" type="checkbox"/>	Value Low	
Record value	200	Value High	
Sample Qty	10.00	Total Qty	10.00
QC Outcome(System)	QC Not OK	QC Outcome(User)	QC Ok
Reason			

Critical Fields

- 1) Parameter- Multiple parameters may be there for inspecting a product.This will be shown from Test Plan which the user selected for the product.
- 2) Record Value- The value that acquired in real during Inspecting the parameter need to be entered.
- 3) Total Qty- Number of quantity which are inspected.
- 4) Qc outcome (User)- If decision from the system need to changed this option can be used.For using this option need to configure in the test plan against the parameter

Critical & onetime setup fields

Non-Critical Fields

1. Sample Quantity: Sample quantity to be inspected.
 2. Reason: Reason for QC Outcome (User), being entered by user manually.
-

Serial number/Lot number (ASI)

Zoom condition's

Validation

Attributes

KONNECT ANALYTICS

Home (19391) | Summary | Quality Inspection(Single):... x

Feedback | Profile | Preference | Change Role | Log Out

Dinesh Raj@XYZ Foundation.*Test Role

Inspection > Attributes

Client: XYZ Foundation

Organization: *

Inspection: 1000280_Test

Attribute Set Instance:

Movement Quantity: 1

Quantity: 1

☒ Active

Activate Windows
Go to Settings to activate Windows.

Critical Fields

Field name with Definition

Critical & onetime setup fields

Non-Critical Fields


Serial number/Lot number (ASI)

If there multiple attribute for single product this will display in attributes Sub tab.

Zoom condition's

Validation

Consumables



KONECT ANALYTICS

Home (19391) Summary *Quality Inspection(Single)... x

Feedback | Profile | Preference | Change Role | Log Out

Inspection > Consumables

Inserted

Client: XYZ Foundation

Organization: HQ

Inspection: 1000726_test

Phys Inventory Line

Description

Quality Consumables

Product

UOM

Quantity: 0

Charge

Activate Windows
Go to Settings to activate Windows.

Critical Fields

- 1) Product- Enter or select the product that needs to be consumed.
- 2) UOM: Unit of Measurement of product to be inspected.
- 3) Quantity- This field represents the quantity needs to be consumed additionally while inspecting.
- 4) Charge- For posting cost of the consumed product.

Critical & onetime setup fields

Non-Critical Fields

Serial number/Lot number (ASI)

Zoom condition's

Validation

Quality Tools

It's use to add asset and change test plan.