

# Tabs

- [Inspection](#)
- [Results](#)
- [Attributes](#)
- [Consumables](#)
- [Quality Tools](#)

# Inspection

**KONECT ANALYTICS** bulk Feedback | Profile | Preference | Change Role | Log Out

Home (19391) | Summary | \*Quality Inspection(Bulk) ✕

Inspection

Inserted

Client: XYZ Foundation Organization:

Document No:

Target Document Type:  Inspection Date: 15/04/2020

Name:

Description:

Reference Document

Vendor:  Partner Location:

Material Receipt:  Shipment:

Warehouse:  QC Warehouse:

QC Outcome(System): QC Not OK QC Outcome(User):

Inventory Move:  Manufacturing Cost Collector:

Subcontract receipt:  Phys Inventory:

Sample Qty: 0.00 Customer RMA:

Total Qty: 0.00 Reference Document:

Tester: Dinesh Raj  Create lines from

Reason:

Status

Document Status: Drafted Document Action:

Activate Windows Go to Settings to activate Windows.

## Critical Fields

- 1) Name- Enter the Name of the document.
- 2) Tester- Name of the person who is inspecting the component.

## Critical & onetime setup fields

- 1) Organization Field- This Field is used to select the organization which you are going to process the order.

2) Target Document Type- This Field is used to select the type of the document that you are going to process.

---

## **Non-Critical Fields**

1) Total Quantity- System will display the quantity from the selected Material receipt document. User can't edit the Quantity.

2) Sample Quantity- System will display the quantity from the selected Material receipt document. User can't edit the Quantity.

---

## **Serial number/Lot number (ASI)**

Attribute can't be created in this document. Only attribute will be taken from the selected Source document.

---

## **Zoom condition's**

1) Material Receipt

2) Shipment (Customer)

3) Subcontract Receipt

4) Inventory Move

5) Internal Use Inventory

6) NCR

---

**Customization**

# Results

The screenshot shows the 'Results' page in the KONNECT ANALYTICS application. The interface includes a top navigation bar with the logo and user information. Below the navigation bar, there is a search bar and a list of tabs. The 'Results' tab is selected, showing a form for a quality inspection. The form contains several fields: 'Client' (XYZ Foundation), 'Organization' (XYZ Offsite), 'Inspection' (1000623\_sd00103), 'Quality plan' (pc assembly), 'Product' (1000002\_Connectors), 'Parameter' (Visual), 'Attribute Set Instance' (empty), 'Active' (checked), 'Record value' (200), 'Sample Qty' (10.00), 'Value Low' (empty), 'Value High' (empty), 'Total Qty' (10.00), 'QC Outcome(System)' (QC Not OK), 'QC Outcome(User)' (QC Ok), and 'Reason' (empty). The 'QC Outcome(User)' dropdown is currently set to 'QC Ok'.

## Critical Fields

- 1) Parameter- Multiple parameters may be there for inspecting a product.This will be shown from Test Plan which the user selected for the product.
- 2) Record Value- The value that acquired in real during Inspecting the parameter need to be entered.
- 3) Total Qty- Number of quantity which are inspected.
- 4) Qc outcome (User)- If decision from the system need to changed this option can be used.For using this option need to configure in the test plan against the parameter

---

## Critical & onetime setup fields

---

## **Non-Critical Fields**

1. Sample Quantity: Sample quantity to be inspected.
  2. Reason: Reason for QC Outcome (User), being entered by user manually.
- 

## **Serial number/Lot number (ASI)**

---

## **Zoom condition's**

---

## **Validation**

# Attributes

KONNECT ANALYTICS

Home (19391) Summary Quality Inspection(Single):... x

Feedback | Profile | Preference | Change Role | Log Out

Dinesh Raj@XYZ Foundation.\*Test Role

Inspection > Attributes

Client: XYZ Foundation

Organization: \*

Inspection: 1000280\_Test

Attribute Set Instance:

Movement Quantity: 1

Quantity: 1

☒ Active

Activate Windows  
Go to Settings to activate Windows.

## Critical Fields

Field name with Definition

---

## Critical & onetime setup fields

---

## Non-Critical Fields

---

## **Serial number/Lot number (ASI)**

If there multiple attribute for single product this will display in attributes Sub tab.

---


## **Zoom condition's**

---

## **Validation**



# Consumables



KONECT ANALYTICS

Home (19391) Summary \*Quality Inspection(Single)... x

Feedback | Profile | Preference | Change Role | Log Out

Inspection > Consumables

Inserted

Client: XYZ Foundation

Organization: HQ

Inspection: 1000726\_test

Description:

Product:

Quantity: 0

Phys Inventory Line:

Quality Consumables:

UOM:

Charge:

Activate Windows  
Go to Settings to activate Windows.

## Critical Fields

- 1) Product- Enter or select the product that needs to be consumed.
- 2) UOM: Unit of Measurement of product to be inspected.
- 3) Quantity- This field represents the quantity needs to be consumed additionally while inspecting.
- 4) Charge- For posting cost of the consumed product.

---

## Critical & onetime setup fields

---

## **Non-Critical Fields**

---

## **Serial number/Lot number (ASI)**

---

## **Zoom condition's**

---

## **Validation**

# Quality Tools

It's use to add asset and change test plan.