

Results

Client: XYZ Foundation

Organization: XYZ Offsite

Inspection: 1000623_sd00103

Quality plan: pc assembly

Product: 1000002_Connectors

Parameter: Visual

Attribute Set Instance:

Active

Record value: 200

Value Low:

Value High:

Sample Qty: 10.00

Total Qty: 10.00

QC Outcome(System): QC Not OK

QC Outcome(User): QC Ok

Reason:

Activate Windows
Go to Settings to activate Windows.

Critical Fields

- 1) Parameter- Multiple parameters may be there for inspecting a product. This will be shown from Test Plan which the user selected for the product.
- 2) Record Value- The value that acquired in real during inspecting the parameter need to be entered.
- 3) Total Qty- Number of quantity which are inspected.
- 4) Qc outcome (User)- If decision from the system need to be changed this option can be used. For using this option need to be configured in the test plan against the parameter.

Critical & onetime setup fields

Non-Critical Fields

1. Sample Quantity: Sample quantity to be inspected.
 2. Reason: Reason for QC Outcome (User), being entered by user manually.
-

Serial number/Lot number (ASI)

Zoom condition's

Validation

Revision #9

Created Thu, Apr 16, 2020 4:39 AM

Updated Fri, Aug 11, 2023 1:27 PM by [Mukund Tulshiram](#)